

XS1
DB9F

| <i>Цепь</i> | <i>Конт.</i> |
|-------------|--------------|
| CD | 1 |
| Rx | 2 |
| Tx | 3 |
| DTR | 4 |
| SG | 5 |
| DSR | 6 |
| RTS | 7 |
| CTS | 8 |
| RI | 9 |
| GND | 10 |
| GND | 11 |

XS2
DB9M

| <i>Конт.</i> | <i>Цепь</i> |
|--------------|-------------|
| 1 | CD |
| 2 | Rx |
| 3 | Tx |
| 4 | DTR |
| 5 | SG |
| 6 | DSR |
| 7 | RTS |
| 8 | CTS |
| 9 | RI |
| 10 | GND |
| 11 | GND |

