















State	OPN	SHRT
OPEN	1	1
SHORT	0	0
OK	0	1
Undefined	1	0

NOTE: OPEN and SHORT signal logic is not valid (indicates antenna short) when Antenna Power jumper is removed or LNA_XEN is high.